

NOTES

For product line drawings, [view model-specific spec sheets](#).

All information contained within this document subject to change without notice.

**DESCRIPTION**

Exposed Manual Specialty Water Closet Bedpan Washer Flushometer

FEATURES

DV-120 with Grab Bar Offset | DV-125 with Grab Bar Offset and Deoseptic Unit

Slimline® Bedpan Washer Diverter Assembly for use in retrofit installations where Flushometers currently are installed and where grab bars are present. Installation meets ADA height requirements.

- Solid One-piece Body Construction
- Counter Balanced Pivot Assembly
- Solid Brass Spray Arm
- High Back Pressure Vacuum Breaker with One-piece Bottom Hex
- Coupling Nut
- 1 1/2" Offset Flush Tube
- Wall Support, Spud Coupling and Flange for 1/2"x" Top Spud
- Vacuum Breaker to be molded from PERMEX™ rubber compound for Chloramine resistance
- Installation height complies with ADA requirements

Diverter Assembly ONLY. Does NOT include Flushometer

DOWNLOADS

- [Slimline Royal/Regal XL Exposed Installation Instructions](#)
- [Slimline Bedpan Washer Repair and Maintenance Guide](#)
- [Additional Downloads](#)

Sloan 10500 Seymour Ave, Franklin Park, IL 60131

Phone: 800.982.5839 • Fax: 800.447.8329 • sloan.com