

### INSTALLATION INSTRUCTIONS FOR SF FAUCET PLUG-IN GANG ADAPTER KIT SFP-35-A


Use these instructions in conjunction with the Installation Instructions furnished with the Sloan SF Faucet.

**!!! IMPORTANT !!!**

**DO NOT PLUG IN THE ADAPTER UNTIL ALL CONNECTIONS ARE MADE**

**A** If necessary, plug in the Cable Extension SFP-37 into the Plug-in Gang Adapter SFP-36.


**B** Install one Cable Splitter SFP-38 for each Faucet. Plug in Splitters as illustrated below.



- Note:**
- A maximum of 8 faucets can be powered by the SFP-36 Adapter. When more than 6 faucets are being used, purchase additional SFP-38 Splitter Cables separately.
  - The maximum recommended distance between the SFP-36 Adapter and the furthest faucet is 39' (12 M). Purchase additional SFP-37 Cables if needed to extend to this distance.
  - The SFP-35-A Gang Adapter Kit can also be used with SLOAN EBF-615 and EBF-650 Series Faucets.

**Note:** For greater distances use additional SFP-37 Cables (Purchase Separately).

#### PARTS LIST



Item No.	Part No.	Description	Quantity
1	SFP-36	Plug-in Gang Adapter (110-240 VAC/6 VDC) (for use w/cable extension and splitter)	1
2	SFP-38	Cable Splitter, 51"/1300 mm	5
3	SFP-37	Cable Extension, 51"/1300 mm	1

When assistance is required, please contact Sloan Valve Company  
Installation Engineering Department at:  
1-888-SLOAN-14: (1-888-756-2614)

The information contained in this document is subject to change without notice.

**SLOAN VALVE COMPANY • 10500 SEYMOUR AVENUE • FRANKLIN PARK, IL 60131**

Phone: 1-800-982-5839 or 1-847-671-4300 • Fax: 1-800-447-8329 or 1-847-671-4380 • www.sloanvalve.com