

#### **CODE NUMBER**

3780432

#### **DESCRIPTION**

1.6 gpf, Polished Chrome Finish, Fixture Connection Top Spud, Single Flush, 1.5 Offset, Offset Vacuum Breaker, Sloan® Exposed Manual Water Closet Flushometer.

### **DETAILS**

Flush Volume: 1.6 gpf (6.0 Lpf)Finish: Polished Chrome (CP)

· Valve: Diaphragm

Valve Body Material: Semi-red Brass

Fixture Type: Water Closet
Fixture Connection: Top Spud
Rough-In Dimension: 27" (686mm)
Spud Coupling: 1 ½" (38mm)
Supply Pipe: 1" (25mm)
Vacuum Breaker: Offset (O)

• Offset: 1.5 (1-1/2-OFST)

### **FEATURES**

- Flush volumes start as low as 1.28 qpf/4.8 Lpf
- Water conservation is aided by the ADA-compliant, non-hold-open handle, which prevents toilet from exceeding intended flush volume
- Flush accuracy is controlled by CID™ technology, also enhancing water efficiency
- Integrity of the product is maintained with the vandal-resistant stop cap
- Durability is facilitated with high copper, low zinc brass castings for dezincification resistance
- Adjustable tailpiece to accommodate different height requirements
- High chloramine resistant PERMEX synthetic rubber diaphragm with Linear Filtered Bypass and Vortex Cleansing Action
- Valve body, Cover, Tailpiece and Control Stop shall be in compliance with ASTM Alloy Classification for Semi-Red Brass
- Valve shall be in compliance to the applicable sections of ASSE 1037.



#### **COMPLIANCES & CERTIFICATIONS**













(ADA Compliant, BAA Compliant, BABAA Compliant, cUPC Certified, Made in the USA, UPC Certified)

#### RECOMMENDED SPECIFICATION

Valve Body, Cover, Tailpiece and Control Stop shall be in conformance with ASTM Alloy Classification for Semi-Red Brass. Valve shall be in compliance with the applicable sections of ASSE 1037 and ANSI/ASME 112.19.2.

### **VALVE OPERATING PRESSURE (FLOWING)**

15–80 PSI (103–552 kPa). Specific fixtures may require greater minimum flowing pressure - consult manufacturer requirements.

# **DOWNLOADS**

- Sloan Exposed Installation Instructions
- Sloan Exposed (Spanish) Installation Instructions
- Control Stop Repair and Maintenance Guide
- Flush Connections Flanges Repair and Maintenance Guide
- Tail Piece Repair and Maintenance Guide
- Sloan Flushometer Repair and Maintenance Guide
- Additional Downloads

### NOTES

All information contained within this document subject to change without notice.

Looking for other variations of the SLOAN 116 product? View the general spec sheet with all options.

# WARRANTY

View Warranty Information



# **ROUGH-IN**

