

### **CODE NUMBER**

24531410

#### **DESCRIPTION**

ST-2459 Water Closet and SLOAN 8111 Flushometer.

### **COMPONENTS**

Flushometer: Code 3790011Water Closet: Code 2102459

### **DETAILS**

• Flush Volume: 1.6 gpf (6.0 Lpf)

Nominal Dimensions: 26 <sup>3</sup>/<sub>4</sub>" × 15" × 13 <sup>1</sup>/<sub>4</sub>" (679 × 381 × 337mm)

# **FLUSHOMETER FEATURES**

- High Chloramine Resistant PERMEX® Synthetic Rubber Diaphragm with Linear Filtered Bypass and Vortex Cleansing ActionTM
- 1" I.P.S. Screwdriver Bak-Chek® Angle Stop with Vandal Resistant Stop Cap
- Vacuum Breaker with Flush Connection
- Spud Coupling and Spud Flange for 11/2" Top Spud
- Sweat Solder Adapter with Cover Tube and Cast Wall Flange
- User friendly three (3) second Flush Delay
- No External Volume Adjustment to Ensure Water Conservation
- Stop Seat and Vacuum Breaker Molded from PERMEX® Rubber Compound for Chloramine resistance
- Infrared Sensor with Multiple-focused, Lobular Sensing Fields for high and low target detection
- Engineered Plastic Cover with replaceable Lens Window
- Courtesy Flush® Override Button
- Four (4) Size AA Batteries included

# **FIXTURE FEATURES**

- White Vitreous China
- Elongated bowl
- Wall mounted, wall outlet
- Siphon jet flushing action achieves 1000g Map score when used with any Sloan flushometer
- Static load rating of 750 lbs (see Notes)
- Water spot area: 101/8" x 93/8" (26 cm x 24 cm)
- 1½" I.P.S. top spud inlet
- 21/8" fully glazed trapway
- · Toilet seat not included
- Static load rating of 750 lbs. (See Notes)



### **COMPLIANCES & CERTIFICATIONS**













(ADA Compliant, BAA Compliant, cUPC Certified, EPD, HPD, WELL Building Standard)

### **DOWNLOADS**

- ST-2459 Installation Instructions
- G2 and ECOS Single Flush Optima Plus Valve Installation Instructions
- SS/ST/SU/WETS/WEUS Fixtures Repair and Maintenance Guide
- Sloan Optima Plus Flushometers Repair and Maintenance Guide
- Additional Downloads

# **NOTES**

All information contained within this document subject to change without notice.

Static load tested according to the procedure outlined in Section 6.7 of ASME A112.19.2. Not recommended for bariatric use.

# WARRANTY

**View Warranty Information** 

Phone: 800.982.5839 • Fax: 800.447.8329 • sloan.com



# **ROUGH-IN**





