

CODE NUMBER

3913226

DESCRIPTION

1.0 gpf, Rough Brass Finish, Fixture Connection Top Spud, Single Flush, 2-15.75 L Dimension, Less Override, Hardwired, Sensor-Operated, 24V, Royal® Concealed Sensor Hardwired Urinal Flushometer.

DETAILS

• Flush Volume: 1.0 gpf (3.8 Lpf)

• Finish: Rough Brass

Power Type: Hardwired (HW)

Valve: Diaphragm

• Valve Body Material: Semi-red Brass

• Fixture Type: Urinal

• Fixture Connection: Top Spud

• Rough-In Dimension: 13 ½" (343mm)

Spud Coupling: ³/₄" (19mm)
Supply Pipe: ³/₄" (19mm)

• L Dimension: 2"-15 3/4" (51-400mm)

Override: Less (L/OR)Voltage: 24V

FEATURES

- Flush volumes start as low as a pint of water
- Water conservation is aided by the ADA-compliant, non-hold-open handle, which, prevents urinal from exceeding intended flush volume
- Flush accuracy is controlled by CID™ technology, also enhancing water efficiency
- Durability is facilitated with high copper, low zinc brass castings for dezincification resistance
- Adjustable tailpiece
- PERMEX synthetic rubber diaphragm with Dual Filtered Fixed Bypass
- Valve body, Cover, Tailpiece and Control Stop shall be in compliance with ASTM Alloy Classification for Semi-Red Brass
- Valve shall be in compliance to the applicable sections of ASSE 1037.

VIDEOS

D

ESS Flushometer



COMPLIANCES & CERTIFICATIONS













(ADA Compliant, BAA Compliant, BABAA Compliant, cUPC Certified, UL Certified, UPC Certified)

RECOMMENDED SPECIFICATION

Valve Body, Cover, Tailpiece and Control Stop shall be in conformance with ASTM Alloy Classification for Semi-Red Brass. Valve shall be in compliance with the applicable sections of ASSE 1037 and ANSI/ASME 112.19.2.

ELECTRICAL SPECIFICATIONS

• Arming Delay: 8 seconds

• Control Circuit: Solid State/24 VAC Input/24 VAC Output

• Flush Delay: 1s

Self-Adaptive Window: ±8

• Sensor Range: 15"-30" (381-762mm)

• Solenoid Operator: 24 VAC

• Transformers (specify separately):

0345154

0345999

VALVE OPERATING PRESSURE (FLOWING)

15-80 PSI (103-552 kPa). Specific fixtures may require greater minimum flowing pressure - consult manufacturer requirements.

DOWNLOADS

- Royal ESS Concealed and Exposed Installation Instructions
- Royal ESS Concealed with Wall Box Installation Instructions
- Royal ESS TMO Installation Instructions
- Royal 140/152/153/195 ESS TMO SWB Installation Instructions
- Royal 152/195 SWB ESS TMO (Spanish) Installation Instructions
- Control Stop Repair and Maintenance Guide
- Flush Connections Flanges Repair and Maintenance Guide
- Tail Piece Repair and Maintenance Guide
- Optima ESS Repair and Maintenance Guide

Sloan 10500 Seymour Ave, Franklin Park, IL 60131

Phone: 800.982.5839 • Fax: 800.447.8329 • sloan.com



- Optima ESS TMO Concealed Repair and Maintenance Guide
- Optima ESS TMO SWB Concealed Repair and Maintenance Guide
- Additional Downloads

NOTES


All information contained within this document subject to change without notice.

Looking for other variations of the ROYAL 197 ESS product? View the general spec sheet with all options.

WARRANTY

View Warranty Information

ROUGH-IN



Sloan 10500 Seymour Ave, Franklin Park, IL 60131

Phone: 800.982.5839 • Fax: 800.447.8329 • sloan.com